
## **Leica Infinity**

Your indispensable bridge between field and office





#### **Data-processing powerhouse**

Leica Infinity – the geospatial office software built for Leica instruments – provides a seamless workflow between field and office to ensure quality at each work phase and improve your overall productivity. And now Infinity reaches a new milestone with its latest release, Leica Infinity which can process data from digital levels, total stations, GNSS sensors and even scanners, making it your indispensable bridge between field and office.



#### Infinitely connected

Leica Infinity is the only true one-bridge solution between Leica field instruments and CAD software. Stay infinitely connected and keep projects moving with fast accessibility, seamless data transfer and a user-friendly interface that will give you greater traceability and control. Leica Infinity also enables faster project overview with 3D, multiple-perspective viewing and a clean, consistent look and feel across all modules.



#### Collect. Verify. Report.

Leica Infinity easily processes data from multiple sites and survey teams and different instrument types. Edit, archive and export directly to CAD applications. You rely on Leica Geosystems instruments every day. Now you can rely on the software solution that connects all of your Leica Geosystems instruments and allows you to collect, verify and report all survey and stake out data in one easy-to-use platform.



### Leica Infinity Office Software - Core

MAP FEATURES

Base Maps

Clip Base Map

Feature Info

Get Feature

Google Earth Export

COORDINATES

Compute Project Coordinates

Coordinate Systems Manager

Transform Local Grid to Local Grid

Import Staked points Results

Import Reference Line Results

Import Staked & Checked Infrastructure

Import Field Data Results

Create Point, Station, Observation

**COGO FUNCTIONALITY** 

Measure Point to Point

Compute Point (COGO)

Shift/Rotate/Scale

**FEATURES PROCESSING** 

Code Table Manager

Import/Export/Create Codelists

Assign Blocks, Layers & Linestyles

Copy Features & Layers from CAD

Create features: Lines, Splines, Arcs, Areas, Circles & Rectangles

Linework Editing

Project Feature

TOOLS

Rename Features Tool

Satellite Availability Tool

**GNSS Reference Station Download** 

Precise Ephemeris Download

Antennas, Targets, and Layer Manager

Localisation Tool

MAGES

**REPORTS** 

Link/Unlink Images

Georeference Images

Applications & Processing Reports

Customizable Reports

Stylesheet Reports LEICA GEOSYSTEMS SERVICES

Leica Exchange, ConX, JetStream

HxGN SmartNet

Leica Spider X-pos

PROJECT DATA SERVICES

12d Synergy

Bricsys 24/7

Autodesk Construction Cloud

Bentley ProjectWise Procore

MAP & GIS SERVICES

HxGN Content Program

Open Street Map

Map Services WFS, WMS, WMST

ArcGIS Online

Portal for ArcGIS

IMPORT

SmartWorx Viva, Captivate Job - DBX

GNSS data - RINEX, MDB, ION, SP3, DAT, GPS,

Level Data - LEV, GSI

Observation Data - GSI, RAW, RW5

HeXML/LandXML - XML

Coordinate Systems - DAT, LOC, DC, CAL

Zeno Mobile - ZIP

Aibot - UAV

LGO Project /CSYS

ASCII

SKI ASCII - ASC

Images - JPG, PNG, TIFF, PDF

Georeferenced Images - JPG, PNG, TIFF

DJI GNSS Flight Data - DJI

BLK360 Images Group - BLK360

Point Clouds - PTS, PTX, LAS, LAZ, E57,

Surface - OBJ, FLY, gITF, GLB

CAD Data - DXF, DWG, DGN

BIM-IFC

ESRI - SHP, Geodatabase

GeoJSON

Geo Viewer - KML, KMZ

InfraGML - XML

NILIM - XML

Trimble - TTM, JXL

NGS - GVX

NGS - DSDATA

EXPORT SmartWorx Viva, Captivate Job - DBX SmartWorx, System 1200, GPS 900 - DBX iCON field ASCII HeXML - XML AutoCAD - DXF, DWG BricsCAD - DWG GeoJSON ESRI - SHP ESRI File Geodatabase - GDB Zeno Data Model - GDB Point Clouds - PTS, PTX, LAS, LAZ, E57, LGS, PLY, PTG Surface - OBJ, FLY, gITF, GLB Export data using stylesheet Coordinate Systems Geo Viewer - KML, KMZ Images - JPG, PNG, TIFF, GeoTIFF Georeferenced DEM - TIFF, GeoTIFF GNSS raw data - RINEX SKI ASCII - ASC Aibotix AiProFlight GeoMos Now! Ellipse neo NGS Blue Book - B and G Files NGS - GVX Pregeo

Bentley - FWD

## Leica Infinity Office Software - Options

	Survey	Advanced Survey	Engineering	Infrastructure	Point Clouds from Images	Point Clouds Registration
PROCESSING TPS						
Traverse, Sets of Angles & Foresights	V					
Update Stations	V					
PROCESSING GNSS		1		1	Į.	
Single Frequency Data Processing (L1)	~	V				
Multifrequency Data Processing (L1, L2, L5)		~			5 	
Multi-constellation Data Processing (GPS GLO GAL BEI QZSS)	V	V				
Static & Kinematic Processing	V	~			5 	
Manual & Automatic Processing	V	V				
Data Analysis Tools	V	~				
Interactive Analysis Charts	V	V				
PROCESSING LEVEL						
Adjust, Join & Split Level Line	V					
Height Observation	V					
Add TP to Library	~					
SURFACES & VOLUMES						
Create Surface: 3D & 2.5D			V			
Add, Remove, Cut Features			~			
Trim, Remove, Fill holes			V			
Contours			~			
Volumes: Stockpile, To Point, To Height, Surface to Surface			V			
Cut Fill Maps			V			
Comparison Maps			V			
POINT CLOUDS	1			<u> </u>	į	<u> </u>
Work with Point Cloud Groups			V		~	
Point Cloud Edits			~		V	
Colour Mode & Filter Point Cloud			V		V	
Point Cloud Classification			V		~	
Clip Plane, Slice or Box			V		V	
POINT CLOUDS REGISTRATION						
Import RTC360 & BLK360						V
Autocloud, Visual Alignment						~
Auto Black & White Targets Extraction						V
Create & Delete Virtual Targets						V
Match Targets, Apply Controls						V
Create Unified Point Cloud (UPC)						~
Downsampling						·
IMAGING - MEASURE POINTS IN IMAGES						
Work with Image Groups	V				V	
Calculate Point From Images	V				~	
IMAGING - POINT CLOUDS FROM IMAGES					<u> </u>	
Orientate Image Groups					V	
Create Dense Point Cloud					V	
Create a Digital Surface Model & Orthophoto					V	
Create Quick Stitch Overview Image					V	
Add Control Points					V	
					~	

# Leica Infinity Office Software - Options

	Survey	Advanced Survey	Engineering	Infrastructure	Point Clouds from Images	Point Clouds Registration
ADJUSTMENT 1D						
Compute Loops, Run-Pre Analysis, Adjustment	V					
ADJUSTMENT 1D, 2D, 3D						
Compute Loops, Run-Pre Analysis, Adjustment		~				
Adjust on Ellipsoid or Local Plane		<b>'</b>				
INFRASTRUCTURE						
Create Vertical & Horizontal Alignment				V		
Create Cross Section & Road Object				V		
Edit, Link & Unlink Cross Sections				V		
Create Checked & Staked Road Report				~		
Create Profile & Section, Tunnel Object				V		
Create As-Build Profile, Tunnel Inspection				V		
Create Road & Tunnel Material Surface				~		

WINDOWS APPLICATION COMPATIBILITY	
Supported OS	Standalone desktop application, Win 11, Win 10, Win server 20nn, VM capable (see installation guide)
Installation	Binaries digitally signed Leica Geosystems AG, Elevated Admin, install by user, silent, enterprise deployment capable
Updates	Binaries digitally signed Leica Geosystems AG, Elevated Admin, install by user, silent, enterprise deployment capable
Licensing	Software license with offline activation capabilities, license server hosted on local machine or within local network
User rights to run app	User WRM
DATA SECURITY	
GDPR, Personal Identifiable Information (PII)	PII not stored, please read more: hexagon.com/legal/privacy-notice
Loadable data in transit	TLS1.2/1.3
Communications, ports	No mandatory external data communication, IT Configurable
Compliance	Refer to software terms and conditions: leica-geosystems.com/about-us/compliance-standards/legal-documents
Application third party dependencies	No dependencies
Cloud services	No mandatory external cloud services dependencies

SYSTEM RECOMMENDATION	NS					
Operating System		Windows 10 - 64 bit, Windows 11				
Input		Keyboard, mouse with wheel				
HARDWARE						
	Minimum	<b>Recommended</b> TPS, GNSS, Level processing	Recommended Image processing, Scan registration			
Display	1024 × 768 px	Dual 1920 × 1280 px	Dual 1920 × 1280 px			
Processor	Multi-core 2.4 GHz	Multi-core 3.5 GHz or greater	Octa-core 3.5 GHz or greater			
RAM	8 GB	32 GB or more	64 GB or more, XMP enabled			
Disk Storage	100 GB	SSD of 1 TB or more	SSD of 2 TB or more			
Graphics	Direct X9 compatible	Direct X11 compatible	Direct X11 compatible			
	512 MB	8 GB or more, CUDA capable	16 GB or more, CUDA capable			

Copyright Leica Geosystems AG, 9435 Heerbrugg, Switzerland. All rights reserved. Printed in Switzerland – 05-2025. Leica Geosystems AG is part of Hexagon AB. 808992en – 05.25

### Leica Geosystems AG

Heinrich-Wild-Strasse 9435 Heerbrugg, Switzerland +41 71 727 31 31

